Preface[™] Conductor's Stand



• 238D001 15.3 lbs (6.9 kg).

- 18-1/2" high x 29" wide (470 x 737 mm), 1.2 mm thick aluminum desk.
- 12-1/2" x 25" x 2" (318 x 635 x 51 mm), 2 mm thick aluminum storage box for out of site storage of additional scores, papers, etc.
- Storage box extends the full width of the desk providing additional desk strength.
- · Integrated storage box allows easy access from either side of the desk.
- Side access to the storage box prevents unexpected spills if desk is tipped.
- · Bolt-through desk attachment to prevent desk from coming off unexpectedly.
- Curved desk shape for additional aesthetic appeal.
- Double upright posts with brass spring height adjustment mechanisms adjust height of desk from 25-1/2" to 49-1/4" (648 to 1251 mm) desk lip to floor.
- Inner tubes of upright posts are black E-coat finish for a formal all-black appearance.
- 12-gauge double base assembly with 14-gauge tie bar for additional strength.
- · Wobble-free base attachment: upright posts sit in the base collars for additional stability.
- 19" x 21" (483 x 533 mm) Base footprint for exceptional stability.
- Durable black powder-coat paint finish.
- UL GREENGUARD Certified Product certified for low chemical emissions: ul.com/gg UL 2818.
- Environmental attributes and LEED compliance for these products can be found at www.wengercorp.com/GREEN
 or by contacting your Wenger representative.
- · Five-year warranty.

Accessories

Electric Music Stand Light


Classic stand light fits all Wenger stands, and most other manufacturers' stands.

1090001 Music Stand Light, 14 oz. (0.4 kg)

LED Music Stand Lights

Compact, attractive, and adjustable, these battery-operated stand lights work with all Wenger stands.

- Features all-LED technology, so no bulbs to replace.
- 237A040 HammerHead LED Music Stand Light, 2.1 oz (0.06 kg)
- 237A035 Encore LED Music Stand Light, 4.3 oz (0.12 kg)
- 237A033 Orchestra Music Stand Light, 10.2 oz (0.29 kg



Accessories continued on next page.

Accessories (continued)

Hands-Free Page Turner

A rugged hands-free device for turning the pages on your digital sheet music. Simple setup and operation make this a great solution for musicians who need a hand.

- 040A142, 0.55 lbs (0.24 kg)
- Tap the foot switches to turn the pages on your digital sheet music forward or backward.
- No messy cables, connects wirelessly to tablets or computers up to 60' (18 m) away using secure Bluetooth technology.
- Internal rechargeable battery, up to 100 hours between charges.
- Nearly indestructible, made of same material as bullet-proof glass.

Universal Tablet Mount, Single

The perfect holder for most models of tablets.

Clipping your tablet in place is easy and secure.

No more resting your tablet on a stand, amp, floor, etc.

040A154, 15 oz (0.42 kg)

- Attaches to a standard 5/8" (16 mm) threaded stand or any music stand shaft using our Side Mount Extension.

Side-Mount Extension

Mount your tablet to the shaft of your music stand or mic stand.

040A140, 0.45 lbs (0.20 kg)

- Use your tablet with a traditional music stand or mic stand.
- Heavy duty steel extension bracket fits shafts up to 1" (25 mm) in diameter.
- Accepts our Universal Tablet Mount and other standard 5/8" (16 mm) threaded stand devices.
- 8" (203 mm) long with 6.25" (159 mm) extension from the shaft.





(shown on traditional music stand)









 WENGER CORPORATION
 Phone 800.4WENGER (493-6437) Worldwide +1.507.455.4100 | Fax 507.455.4258 Worldwide +1.507.774.8576

 Parts & Service 800.887.7145 | Canada Office 800.268.0148 | Web wengercorp.com | 555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448

 JR CLANCY
 Phone 800.836.1885 Worldwide +1.315.451.3440 | Fax 877.836.1885 Worldwide +1.315.451.1766 | Web jrclancy.com

 GEARBOSS
 Phone 800.493.6437 | email gearboss@wengercorp.com | Web gearboss.com | 555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448